

L. J. POLYTECHNIC

L. J. Campus, Between Sarkhej-Sanand Circle & Kataria Motors,

S.G. Road, Ahmedabad-382210.

Ph. 079-29096539.

Lab Manual

(O)f

Network

Mamagennent and Administration.

DEPARTMENT OF COMPUTER ENGINEERING

SEMESTER - 6

LJ Polytechnic, Ahmedabad


COMPUTER ENGINEERING - SEMESTER 6 NETWORK MANAGEMENT AND ADMINISTRATION [3360703] PRACTICAL LIST

Pr #.	PRACTICAL DEFINITION
1	Execution of Basic TCP/IP utilities and commands.
2	Installing and Configuring Virtual Machine VMware.
3	Creating Windows Server Boot Disk.
4	Installing Windows Server 2012 R2 on VMware.
5	Configuring Windows Server 2012 R2 on VMware.
6	Installing Windows 7 Operating System on VMware.
7	Configuring Windows 7 Operating System on VMware.
8	Installing Active Directory Using Server Manager.
9	Promoting Server to Domain Controller.
10	Creating Active Directory Objects.
11	Create new Users & assign privileges/ Permission.
12	Modify/ Delete/Deactivate Users and groups.
13	Install and Configure DHCP on Server 2012.
14	Install and Configure DNS on Server 2012.
15	Setting up and configuring local print device.
16	Setting up and configuring network print device.
17	Implementing Group Policy in Windows Server 2012 R2
18	Creating Mapped Drive using Group Policy.
19	Manage Desktop Configuration using Group Policy
20	Installing and Configuring Backup Services.


PRACTICAL 13

Practical Definition:


- ➤ Install and Configure DHCP on Server 2012.
- 1. Logon on to your root domain controller. Open Server manager and click **Add roles and features**.




2. In the Add Roles and Features Wizard, click Next.




3. In the Select installation type page, select Role –based or feature-based Installations, click Next.




4. On Select destination server page, select your server name and then click Next.




5. On the **Select server roles** page, select the **DHCP Server** check box.




6. In the Add Roles and Features Wizard, click Add Features.




7. On the Select Server Roles page, click Next.




8. On the Select features page, click Next.



9. On the **DHCP Server** page, click **Next**.



- 10.On the Confirm installation selections page, click Install.
- 11.On the Installation progress page, wait until the Installation succeeds.




PRACTICAL 14

Practical Definition:

➤ Install and Configure DNS on Server 2012

Configure a Static IP Address

1. From the desktop, use the keyboard combination of the **Win+r** keys to bring up the run Prompt. In the open box, type **cmd** and click OK.



2. At the command prompt, type **ipconfig.** This brings up the dynamic IP address assigned to your network adapter. Take not the encircled information as you will need it to configure your adapter statically.

```
Administrator: C:\Windows\system32\cmd.exe

Microsoft Windows [Version 6.3.9600]
(c) 2013 Microsoft Corporation. All rights reserved.

C:\Users\Administrator\piconfig

Windows IP Configuration

Ethernet adapter Ethernet0:

Connection-specific DNS Suffix : fe80::59aa:9f56:ba19:93bx12
IPV4 Address . . : f92.168.225.131
Subnet Mask . . . : 192.168.225.25

Default Gateway . . : 192.168.225.2

Tunnel adapter isatap.\(AB8C9F7D-3175-422E-86E3-3A001BB24625\):


Media State . . . . . . . . . . . . . . . . . . Media disconnected
Connection-specific DNS Suffix . :

C:\Users\Administrator\
```


3. From the lower right of your taskbar, right click on your network status icon and select 'Open Network and Sharing Center.'




4. Once the Network and Sharing Center opens, from the left menu click on 'Change adapter settings.'



5. From the properties page of your Ethernet adapter double click **Internet Protocol Version 4 (TCP/IPv4).**



6. This brings up the TCP/IP v4 properties page. Select the radio button for, "Use the following IP Address".



7. Provide IP address:


Subnet mask:

Default gateway:


Preferred DNS server:

Etc.


Then click **OK**. One more time **Ok** to close Ethernet0 properties.




1. Launch your Server Manager. On Dashboard, click on "Add roles and features."




2. You will get the "Add Roles and Features Wizard," click Next.




3. Select "Role-based or feature-based installation," click Next.




4. In "**Select destination server**" screen, most likely you will only see one selection, which is the server you are on if not, select the **server** you want to add the DNS role to and click **Next.**




5. Check the "DNS Server" box.




6. A smaller window will launch to confirm that there are other features that need to be installed with your DNS role, click on "**Add Features**" then click **Next**.




7. You do not have to select anything in the "Select features" screen, click Next.




8. In **DNS Server** page click **Next**.




9. Here we just have a confirmation of what we are installing and what features, click **Install**.



10. You will see the installation progress here.



11. Once installation is completed, click Close.



12.Once the installation is done, DNS should be installed; you will also notice an entry for **DNS** inside the context menu for **Administrative tools**.

